



---

## Suggested Installation Instructions for: 166-000 Wheel Maskers



**Please read and follow these and all instructions completely before beginning installation.**

Your kit contains the following: 2 Wheel Maskers, 8 Holding Clips – No Screws Needed!

1. It is not necessary to remove the wheel from the vehicle.
2. Remove all flaked and chipped paint from the rim with a stripper or a wire brush. Sand if necessary.
3. Remove all dust, dirt, and grease with grease and wax remover.
4. Adjust metal paint masker to grip outside of the wheel rim bead and make contact with the surface of the tire. See photo at right.
5. Hold wheel masker in this position and secure the metal clips onto the overlapping metal masker.
6. Wheel rim is now ready to be painted.
7. Allow paint to dry before removing the metal clips and wheel masker from the wheel.
8. Repeat steps 2 thru 7 for any other wheels to be painted whether on or off the vehicle.
9. Clean wheel masker as required.

**HELPFUL HINT:** Great for cleaning as well! Most cleaners and protectants for wheels or tires don't go well together. Use Mid America's Wheel Masker to keep them separated.