
Suggested Installation Instructions for:
304-965 (Sedan Only) and 304-966 (Sedan Only)
Beetle 1965-1977, Super Beetle 1971-1975 Basic Door Panel Set

DIRECTIONS FOR SAFE AND PROPER INSTALLATION

1. 1965-66 Punch out hole A
2. 1967-77 Punch out hole B

Trim the vinyl flush with the hard back opening.

