



Suggested Installation Instructions for Product Number:
617-212, 617-210, 617-213, 628-053
Corvette Front Sway Bar

Count on Mid America Motorworks for all your Corvette Parts and Corvette Accessories

1. Start by breaking the lug nuts loose on your front wheels.
2. Then securely raise and support the vehicle so the front tires are suspended and you have adequate space to work under the front of the vehicle.
3. Remove the lug nuts and front wheel, tire assemblies.
4. Next loosen and remove the nuts from the sway bar end links on both sides of the vehicle. **(B)**
5. Remove the four sway bar insulator retaining bolts from the frame rail. **(A)**
6. Hold the new front sway bar in place and install the insulator brackets and bolts into the frame. (Tighten to 40 lb ft) **(A)**
7. Install the front sway bar end links on both sides of the vehicle. (Tighten to 35 lb ft) **(B)**

