

MID AMERICA



MOTORWORKS™

Pursue your passion here®

Suggested Installation Instructions for Product Number:

619-483

1997-2004 Emblem Inserts, Stainless Steel

Count on Mid America Motorworks for all your Corvette Parts and Corvette Accessories

Items Included:

8-Stainless Inserts

1. Clean emblem area first with soap and water to remove any dirt then with household isopropyl alcohol to remove any and all waxes. Let dry.
2. Place each insert into position and make note of its position.
3. Peel red liner and reposition in place. Press firmly to set adhesive.

Note: Care must be taken when cleaning your inserts. It is a good idea to lightly dust your inserts with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.