



---

**Suggested Installation Instructions for Product Number:****621-905****2006-2009 Z06 Stainless Side Spears w/Perforated Vent Grilles****Count on Mid America Motorworks for all your Corvette Parts and Corvette Accessories**

---

BE SURE TO INSTALL YOUR PERFORATED VENTS (PART # C608-Z) BEFORE BEGINNING THIS INSTALLATION!  
UNLESS YOU ORDERED YOUR SPEARS ONLY KIT WITHOUT PERFORATED VENTS!

**PARTS INCLUDED:**

PART C608-Z and

4-Stainless Spears

2-Adhesive Promoter Packs

1. Clean the painted surface just in front of the black factory plastic side vents and the horizontal vent ribs with household isopropyl alcohol to remove all dirt and wax. Once this is done swipe the painted area once with the adhesive promoter provided to the area horizontal to the vent rib where the spears will be mounted.
2. Place each spear in position to check the fit and also to get acquainted to just where they sit. Once you have a good idea as to their positioning apply a full dab of 100% clear household silicone to the inside of each spear so that the silicone will come in contact with the plastic vent rib. Peel the red release liner from each spear and firmly press them into position making sure they sit nice and straight.
3. Let dry for 24 hours.

