



**MID AMERICA
MOTORWORKS™**

INSTRUCTION SHEET

Part Number

106-908

Application: 1953-2018 Corvettes

Part Includes

- 1 - Container of HOT STUFF
- 1 - Application Stick

Hot Stuff- Exhaust Manifold Dressing



Tools Needed



KEEP OUT OF REACH OF CHILDREN!

WSTEP 1.

Wire brush to loosen rust and grease from the exhaust manifold.

STEP 2.

Apply a thin coat of HOT STUFF with a small brush.

STEP 3.

Air Dry for 2 Hours at room temperature then heat cure by running the engine for 10 minutes. If manifold will be assembled later, cure in an oven at 275° F for 1 hour.

STEP 4.

The durable raw cast iron appearance is now complete. The space age blend of stainless steel and cermanic will withstand temperatures of 2400° F.

STEP 5.

Be sure to clean your hands and tools with soap and water. HOT STUFF won't be thinned without compromising the product.



2900 N. Third Street, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

000-000