



Application: 1949-1977 Standard Beetle

Part Includes

- LED Array
- Wiring Pigtail
- Insulated Connectors
- Stainless Steel Brackets



Tools Needed



STEP 1.

This retro fit kit is designed for VW's with a 12 volt negative ground battery and will not work with 6 volt systems.

STEP 2.

DISCONNECT BATTERY. DO NOT skip this step. Also, do not try to "test" the LED array by connecting the leads directly to a battery charger. Permanent damage could occur to the LED array if you fail to heed these steps.

STEP 3.

Remove the taillight housing from the car.

STEP 4.

Gently remove the retaining wire holding the bulb holder to the taillight housing and save for later. Cut the two wire leads going to the bulb.

STEP 5.

Install the included foam gasket to the rim of the LED taillight lens.



STEP 6.

Install the LED taillight into the taillight housing and re-install the retaining wire.



aircooledvws



@acvwpassion



MAMotorworksACVWPassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



306-831

Description (cont.)

STEP 7.

Using the included blue quick connectors, connect the wire leads from the LED unit to your car according to the chart below.

Green = Ground

Red = Stop

Black = Tail

STEP 8.

Connect the green wire from the LED taillight to a good body ground

STEP 9.

Reinstall the taillight housing onto the car

STEP 10.

Repeat for the other side

STEP 11.

Reconnect the battery

STEP 12.

Test all taillight functions. Enjoy!