



**Application:** 1984-1990 Corvette

**Part Includes**  
12 - Louvers

## Side Port Louvers



### Tools Needed



Search: **Grilles**  
[www.mamotorworks.com](http://www.mamotorworks.com)

### DIRECTIONS FOR SAFE AND PROPER APPLICATION

**STEP 1.**

Insert Louvers in side ports and pull them to the point that you can align them.

**STEP 2.**

Make sure they are evenly spaced before proceeding in pulling them back into place. One extra louver is provided for your convenience.

**STEP 3.**

Make sure not to drop the louvers into the side port; they are not easy to retrieve. When washing your Corvette, the louvers may be removed. If you wish to leave them on, try to avoid a direct high pressure water flow on the louvers.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
©Mid America Motorworks, Inc. All rights reserved.