



Application: 1997-2005 Corvette



Search: *Decals and Body Emblems*
www.mamotorworks.com

Part Includes

1 - S.S. Lettering Kit

Front Stainless Steel Lettering Kit



Tools Needed



DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

Thoroughly clean the CORVETTE indented surfaces with an alcohol swab.

STEP 2.

Carefully apply adhesion promotor to indented surface where the letters are to be placed. Allow adhesion promotor to dry completely.

STEP 3.

Remove protective film from the letters and carefully position securely in place. Carefully polish with a soft cloth.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.