



**Application:** 2005-2013 C6 Corvette

**Part Includes**

1 - Vinyl Window Decal

1 - Squeegee

# Corvette C6 Script Windshield Decal



**Tools Needed**



Search: **Decal**

[www.mamotorworks.com](http://www.mamotorworks.com)

**NOTE:** The spacing and contour of the letters have been designed for application from the backing paper. The tops of the letters have a transfer paper (tape) attached that will be used to squeegee the letters to the glass. If you are uncomfortable with installing this application yourself, it may be in your best interest to use a professional vinyl installer by contacting a local sign shop in your area.

**STEP 1.**

Clean the windshield thoroughly. Straighten and place the lettering on the windshield as close to center as possible using the interior rear view mirror bracket and the " O " marking as a guide.

**STEP 2.**

Attach the lettering sheet temporarily to the windshield at the center point and at each L/R end by using strips of masking tape.



We suggest setting the actual lettering 1 1/2 inches down from the top center of the windshield header. To get the exact center left to right, measure starting from the right side (passenger) 2 1/4 inches from the BOTTOM of the letter **C** back to the passenger windshield molding edge.

**STEP 3.**

Once you have the letter sheet positioned, apply a solid strip of masking tape across the entire edge of the letter template (1/2 to the template and 1/2 to the windshield glass). The tape will act as a HINGE so you will be able to lift the letter template up and back.

We recommend you cut the letter sheet at the divider markings between the **C** and the **O**, and between the **R** and the **V**. This will give you a smaller section to work with at a time. A good pair of scissors is suggested to make the cut.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.



## **Description (cont.)**

### **STEP 4.**

Working from the passenger side first, lift the hinged half of the letter sheet up and slowly peel the underside backing paper from the letters leaving them sticking to the transfer tape.

### **STEP 5.**

At this point apply glass cleaner using a spray bottle "MISTING" the under side of this section of the letters. Applying the fluid keeps the letters from adhering immediately to the glass, creating less chance of bubbles.

### **STEP 6.**

Lower this section of letters down to the glass and begin to *gently* squeegee the top of the application tape and letters using the enclosed squeegee starting with the letter **C** and moving to the center **V**. This will remove the water and any bubbles. DO NOT remove the transfer tape at this time. Wait until all the fluid evaporates and the adhesive is dry.

Next go to the driver side and repeat the same process for the other half of the letter template.

### **STEP 7.**

When finished with the second side of the template and letting it dry, go back to the first side and begin removing the transfer tape from the top of the letters. If the letters pull from the glass and are not sticking, they are not dry and need to finish drying. If the letters are sticking to the glass, very slowly pull back the transfer paper at a close angle to the letters (not pulling straight up). At the same time, lightly squeegee the letters if there appear to be any bubbles.



**Description** (cont.)



**Description** (cont.)