



Application: 1953-2019

638-508

Part Includes

1 - Component

Semi-Custom Universal Car Cover



Search: *Car Covers*
www.mamotorworks.com



Tools Needed

CAUTION!

- Make sure that your vehicle's exterior is clean and dry before installation. Putting a cover on a dirty or wet car can harm the finish of your paint.
- It is not recommended to put any cover on a freshly painted finish. If you are in doubt about the durability of your finish consult a professional automotive painter or body shop. Some paints should cure for 6 months before using a cover.
- In rare circumstances some moisture can freeze under the cover and it will stick to the vehicle. Don't remove the cover if frozen to the vehicle. Either wait for it to thaw or pour warm water on the cover and gradually lift the cover off.
- Never cover a vehicle that has open windows, the convertible top off or that will be towed.
- Never cover a hot exhaust pipe.
- It is recommended the cover be removed at least once every 60 days for at least two hours.

INSTALLATION INSTRUCTIONS:

STEP 1.

If you do not have a retractable antenna, you will need to remove the antenna mast (refer to your vehicle's service manual for this procedure) or follow steps 7 and 8 below to insert a grommet.

STEP 2.

Start by unrolling the cover on top of the vehicle and locate the tag that is sewn in the FRONT elastic strap of the cover.

STEP 3.

Now that you have determined the front from the back of the cover, you can proceed to the middle section of your vehicle.

STEP 4.

If equipped with mirror pockets, place one mirror pocket over the driver side mirror then proceed to the other side. If you have a passenger side mirror then cover it with the other mirror pocket.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.



Custom Car Cover

STEP 5.

Next, go to the front and pull the cover down over the bumper or fascia panel.

STEP 6.

Repeat that process on the rear of the vehicle.

STEP 7.

Now, locate the spot where the non-retractable antenna will need to come through the cover and make a small hole (no bigger than 1/2" in diameter).

STEP 8.

You can make the hole with sharp scissors, or a soldering iron. If you use scissors, just simply cut an eight sided star pattern for the hole. Then you can snap the provided grommet in place to keep the hole from tearing.

STEP 9.

You may choose to install the lock and cable set (provided with many PERFORMANCE CHOICE® covers). Not only is the lock and cable a theft deterrent, it helps keep the cover on during windy conditions.

STEP 10.

On some covers, you will notice two concealed plastic grommets that will accept this cable (one on each side under the door).

CARE INSTRUCTIONS:

We recommend washing the cover in a bath tub or a large bucket with cold or warm water and a small amount of a mild

detergent such as Woolite®. A double or triple-sized commercial washing machine can be used, but only with cold water and 1/4 cup of detergent. Once you have washed and thoroughly rinsed the cover, we recommend you line or air dry the cover. Electric or gas dryers should never be used.

NOTE: Always make sure your car is clean and dry before using a car cover. Before use, unfold the car cover and get a friend to assist you in shaking any loose manufacturing dust, powder or sewing residue off of the car cover. After shaking off loose dust, install car cover as directed. Returns due to dust on the car cover will not be accepted.