



Application: Corvette 2005-2013 C6

Part Includes

- LED Brake Lights
- All necessary wiring

Lower Brake Lights LEDs



Tools Needed



Search: **Light**
www.mamotorworks.com

STEP 1.

Raise rear of car and support with jack stands. Using a #15 torx driver, remove both taillights on one side for access to 3rd brake light. Reach through the taillight opening and release the 3rd brake light connector.



STEP 2.

Drop the connector through the opening around the license plate lights.



STEP 3.

Pull back some of the black covering over the wires so you can install the connectors. Place one wire in each connector, fold closed and squeeze gently with a pair of pliers until it latches.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 4.

Measure and mark the center of the LED strip and also the center of the channel on the rear fascia. It helps to tape it in place so you can accurately mark where to drill the 1/8" hole for the wire. Drill the 1/8" hole and pass the wire through.



STEP 5.

Reach through the taillight opening and find the wire you routed through the hole. It may be under a panel you can reach under and find the wire. Pull it through the same opening as the 3rd brake light connector. Strip about 1/2" of insulation and fold the wire in half so there is more wire to crimp. Now install the 2 male connectors and crimp them tightly.



STEP 6.

Now plug the red LED wire into the back of the connector on the blue wire. Plug the black LED wire into the back of the connector on the black wire. Test the system before mounting by TURNING ON THE KEY and have someone hit the brake pedal. Once the LED strip is working you can mount it. See next page.





Description (cont.)

STEP 7.

Aggressively clean the channel where the LED strip will mount with the supplied alcohol pads, degreaser or Acetone. You can tape off the area around the channel to prevent any straining that may occur. Next, cut the very top off the adhesion promotor pack. As you remove the sponge, squeeze all the excess fluid you can back into the packet to have enough for the entire area. Apply a THIN coat only in the channel that the strip mounts in. Let it dry for 5 minutes.

STEP 8.

Start mounting the strip at the end where you drilled the hole, NOT IN THE CENTER. Peel the backing as you go and pay close attention to the corners as you will have to bend and form the strip to the corners. Press and hold for a couple minutes to be sure the strip sticks. Work the strip all the way across. It helps to have a helper come behind you to keep pressing the strip to stay in place. Test again after you are finished and don't forget to TURN THE KEY ON WHEN TESTING. You can also apply a small dab of black silicone to the hole to seal it up.

DON'T FORGET TO PLUG THE UPPER BRAKE LIGHT BACK IN!

Wire tie the LED wires as needed and reinstall the brake lights.

