



Application: 1986-1991 C4 Corvette – L98 with 2-Bolt flange only

Part Includes

- 1 - Y-Pipe Section
- 1 - Passenger Side Extension Pipe
- 1 - Passenger Side Muffler Section
- 1 - Driver Side Extension Pipe
- 1 - Driver Side Muffler Section
- 4 - Band Clamps

Cat-Back SS Exhaust System



Tools Needed



Search: **Exhaust Systems**
www.mamotorworks.com

NOTE: It helps to do this installation on a lift if you want to get the factory mufflers out in one piece. If a lift is not available you may have to cut the factory axle hoop away from the muffler.

STEP 1.

Unbolt the flange that connects to the catalytic converter.

STEP 2.

Remove the factory nuts from the rear of the mufflers and set aside. Loosen the brackets that hold the rear of the mufflers and let hang in place.

STEP 3.

Remove the existing system.

STEP 4.

To install the B & B system, align the Y-Pipe up to the factory catalytic converter and slide the Y-Pipe into the existing hanger. Reusing the existing hardware bolt the flange to the catalytic converter finger tight at this time.

STEP 5.

Slide the supplied clamps over the Y-Pipe and slip the extension pipes onto the Y-Pipe. Tighten the clamp loosely at this time.

STEP 6.

Position the new mufflers into place by inserting the mounting bolt at the rear of the muffler into the factory hanger. Mate the extension pipe and muffler inlet with the supplied clamp and just tighten them enough to still allow for movement while aligning the system. *But do not tighten them completely. Install the existing nut onto the mounting bolt at the rear of the muffler.

STEP 7.

With all components in place, use a straight edge along the bottom of the tips for proper alignment. Keeping in mind that it will take some time to align them correctly.

STEP 8.

Then start by tightening the flange in front of the system first and then the clamps connecting the muffler sections making sure everything is still in alignment. Finish by tightening the existing brackets and the existing nuts at the rear of the mufflers.

STEP 9.

Fire the car up and take it for a spin around the block making sure there are no rattles.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

BILL OF MATERIALS					
ITEM	QTY.	U/M	PACKING	ISP INT	DESCRIPTION
1	1	EA			Y-PIPE SECTION
2	1	EA			DRIVER SIDE MUFFLER SECTION
3	1	EA			PASSENGER SIDE MUFFLER SECTION
4	4	EA			CLAMP - BAND
5	1	EA			DRIVER SIDE EXTENSION PIPE
6	1	EA			PASSENGER SIDE EXTENSION PIPE
7					
8					

