



Application: 1997-2004



Search: *Radios, Antenna & Cameras*
www.mamotorworks.com

Part Includes

1 - Component

Antenna Bypass with Wiring Harness



Tools Needed

STEP 1.

Remove interior panels at right rear corner of cargo area.

STEP 2.

Disconnect courtesy lamp harness.

STEP 3.

Locate pink wire that leads to antenna, then cut the pink wire.

STEP 4.

Splice switch wires into pink wire using supplied connectors and heat shrink tubing.

STEP 5.

Test antenna function using before reinstalling panels.

STEP 6.

Route wire along passenger side of interior, tucking wire between carpeting and interior panels.

STEP 7.

Recommended places for mounting toggle switch for easy access: inside the console, on the driver's side of the console.

STEP 8.

Reconnect courtesy lamp harness and reinstall interior panels in cargo area.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.