



Application: 2005-2013 Corvettes



Search: **Lighting, Exterior & Interior**
www.mamotorworks.com

C6 Exhaust Enhancer Plate LED Lighting Kit



Tools Needed



OTHER HELPFUL TOOLS: Wite coat hanger, pliers, jack and jack stands.

Step 1: This shows the location of the exhaust leds. Led bar is attached to the rear of the rear facia brackets facing the front of the vehicle. Note the routing of the wires. (white arrow) going up towards the license plate lights. This is where the wire hanger comes in handy.



Step 2: This shows the rear facia bracket that the LED bar attaches to on the back side between these 2 screws. LEDs face the front of the car. Center the bar between the brackets, peel and stick the LED bar to the backside of the brackets between the screws.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

Step 3: Remove 2 screws that hold one of the license plate lights in place. Using the coat hanger, route the hangar from the exhaust plate up to the license plate light. Tape the end of the led wires to the hanger and pull it up to the license plate light as in this picture.



Step 4: Strip back some of the tape holding the wires together to give room for the quick taps. Center the wire in the foldable connector and close it together with pliers until it locks in place. Connect the led wires into the back of the connectors. Black to the black wire and red wire to the dark brown wire. Push leads in firmly until they bottom out on the connector as in this picture.



Turn on the lights to test the leds. Once all is working re-attach the license plate light. Secure any extra length of wire to keep away from exhaust pipes. Enjoy the new lights!