



**Application:** 1975-1982



Search: *Lighting, Exterior & Interior*  
[www.mamotorworks.com](http://www.mamotorworks.com)

**Part Includes**


1 - Component

# Bubble Taillight Conversion Kit



## Tools Needed

### MID AMERICA SOCKET COLOR CODE



**NOTE:** This installation will eliminate the use of backing lights on your Corvette!

To make the inside tail lamps function as the outside lamps do, wire the supplied socket into the existing and corresponding tail lamp harness as shown. Scotch locks are supplied for splicing purposes.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**


**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

### SPLICING SCHEMATIC



### EXISTING SOCKET COLOR CODE

#### DRIVER SIDE

BLACK - Ground

BROWN - Running Lights

YELLOW - Stop & Directional Signals

#### PASSENGER SIDE

BLACK - Ground

BROWN - Running Lights

GREEN - Stop & Directional Signals

**NOTE:** Due to variations at the factory, or past repair to your Corvette's tail lamp wiring, the existing socket color codes may not match your vehicle. Simply use a test light to determine the function of your existing socket's wires, then refer to splicing schematic.